

LA PROVENCE & PETITE PROVENCE

Baking Instructions

U-Bake Cinnamon Rolls

1. Place the frozen Cinnamon Rolls 3 inches apart on a baking sheet.
2. Let them proof at room temperature for 6 to 8 hours. (*Hint: Get these set up to proof before you go to sleep and they'll be ready to bake when you wake up.*)
3. Preheat your oven to 350°.
4. Bake for 18-20 minutes, or until golden brown.
5. Let cool for 1 minute before spreading the icing over them.

Cinnamon Roll Ingredients: Dough (flour, milk, butter, egg, sugar, yeast, salt), cinnamon, sugar, cornstarch